

L5P

## MULTI-SHELF HIGH-BACK PRODUCE MERCHANDISERS Medium Temperature Refrigerated Display Cases

This manual has been designed to be used in conjunction with the General Installation & Service Manual.

Save the Instructions in Both Manuals for Future Reference!!

This merchandiser conforms to the Commercial Refrigeration Manufacturers Association Health and Sanitation standard CRS-S1-96.

PRINTED IN Specifications subject to	REPLACES	,	ISSUE		PART		
IN U.S.A. change without notice.	EDITION	1/97	DATE	7/99	NO.	9027540	rev. B

Tyler Refrigeration Corporation \* Niles, Michigan 49120

## **CONTENTS**

	Page
Specifications	
L5P Specification Sheets	
Pre-Installation Responsibilities	(See General I&S Manual)
Installation Procedures	
Carpentry Procedures	
Case Pull-Up Locations	
Electrical Procedures	
Plumbing Procedures	(See General I&S Manual)
Refrigeration Procedures	(See General I&S Manual)
Defrost Information	
Defrost Control Chart	
Installation Procedure Check Lists	(See General I&S Manual)
Wiring Diagrams	
L5P Domestic & Export (50Hz) Case Circu	its 7
Case Lighting Circuits	
Cleaning and Sanitation	(See General I&S Manual)
General Information	
Mirror Installation	
Water Spray Accessories	
Produce Handling Tips	
Service Instructions	
Preventive Maintenance	(See General I&S Manual)
Ballast and Lighting Locations	
Parts Information	
Cladding and Trim Parts List	
Operational Parts List	
TYLER Warranty	(See General I&S Manual)
-	

The following Medium Temperature High-Back Refrigerated Produce Merchandiser models are covered in this manual:

#### MODELS DESCRIPTION

L5P 8' & 12' EXTENDED HEIGHT PRODUCE MERCHANDISER

## SPECIFICATIONS

### L5P Multi-Shelf High Back Produce Merchandiser Specification Sheets

MODEL	L5P	L5P
USAGE	WRAPPED	BULK
BTUH/FT	1200	1140
SUCTION®	+20F	+25F
ENTER AIR	+35F	+39F

THE ABOVE RATINGS ARE FOR COMPRESSOR SELECTION ONLY. FOR ENERGY CALCULATION DATA REFER TO THE ENERGY SECTION.

NOTE: FOR COMPRESSOR SIZING INFORMATION REFER TO THE "GOLD" SECTION & FOR LINE SIZING INFORMATION REFER TO THE "BUFF" SECTION OF THE TYLER SPECIFICATION GUIDE.

DEFROST CONTROL			PRESSURE	PRESSURE SETTINGS		
PER DAY	MODE	TIME	CUT IN	CUT OUT	R22	R404A
3	TIME OFF	40 MIN.	65-70#@R22	41-45# @ R22	43#	
WRAP		40 IVIIIN.	81-86# @ R404A	53-58# @ R404A		55#
3-4	TIME OFF	40 MIN.	68-72#@R22	45-54# @ R22	45#	
BULK	40 WIIN.	84-90# @ R404A	58-68# @ R404A		58#	

	CASE-TO-CASE SUCTION LINE SUB-FEED BRANCH LINE SIZING													
	8'	12'	16'	20'	24'	28'	32'	36'	40'	44'	48'	52'	56'	60'
R22 WRAP	5/8"	7/8"	7/8"	7/8"	7/8"	1 1/8"	1 1/8"	1 1/8"	1 1/8"	11/8"	1 1/8"	1 3/8"	1 3/8"	1 3/8"
R22 BULK	5/8"	7/8"	7/8"	7/8"	7/8"	1 1/8"	11/8"	11/8"	1 1/8"	11/8"	11/8"	1 1/8"	1 3/8"	1 3/8"


**SHELVING NOTE:** Shelving usage - 3 shelves maximum. Shelving widths available for this case are 15" and 18". When two sizes are used, the smaller must be used on top.

**CASE BTUH REQUIREMENTS** are calculated to produce approximately the indicated entering air temperature with absolute maximum operating ambient limits of **75F & 55RH**.

The information contained herein is based on technical data and tests which we believe to be reliable and is intended for use by persons having technical skill, at their own discretion and risk. Since conditions of use are outside Tyler's control, we can assume no liability for results obtained or damages incurred through the applications of the data presented. SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE.

A 5.0 - L5P.PUB






120 VOLT ELECTRICAL DATA (AMPS)							
LENGTH STD. FANS ECM FANS							
8'	1.0	.6					
12'	1.5	.9					

STANDARD 120 VOLT LIGHTING (AMPS) T-8/ ELECTRONIC BALLASTS (CANOPY)					
ROWS	8'	12'			
3	1.8	2.6			

OPTIONAL 120 VOLT LIGHTING (AMPS) T-8/ ELECTRONIC BALLASTS (SHELVES)						
ROWS	8'	12'				
1	1.0	1.2				
2	1.4	2.1				
3	1.9	2.9				


\_ALLOW 3" SPACE between the back of this case and the store wall, other cases or coolers to minimize possible condensation problems. FORCED VENTILATION may be necessary in some situations.




## INSTALLATION PROCEDURES

### **Carpentry Procedures**

**Case Pull-Up Locations** 





The L5P models have four pull-ups at each end of the case. Pull-ups A, B, C and D are located as shown and should be installed and tightened starting with A and finishing with D.

# See "General I&S Manual" for line-up assembly instructions.

### **Electrical Procedures**

**Electrical Considerations** 

### **CAUTION**

Make sure all electrical connections at components and terminal blocks are tight. This will prevent burning of electrical terminals and/or premature component failure.

#### NOTE

The raceway houses the electrical wiring, components and terminal blocks for the case. Remove the lower front cladding to access the raceway.

#### Case Fan Circuit

This circuit is to be supplied by an uninterrupted, protected 120V circuit. The case fan circuit is not cycled during defrost on any of these models.

#### Fluorescent Lamp Circuit

L5P case lighting is supplied by T-8 electronic ballast lights. It is controlled by a light switch in each case. The standard lighting is 3-row of T-8 canopy lights. The L5P also offers up to 3 rows of optional shelf lights.

### **Defrost Information**


See "General I&S Manual" for operational descriptions for Off Time defrost control. Defrost Control Chart

		Defrost	
Defrost	Defrosts	Duration	Term.
<u>Type</u>	<u>Per Day</u>	<u>(Min)</u>	<u>Temp.</u>
Off Time	3-4	40	


## WIRING DIAGRAMS


#### ELECTRICIAN NOTE -OVERCURRENT PROTECTION

120V circuits should be protected by 15 or 20 Amp devices per the requirements noted on the cabinet nameplate or the National Electrical Code, Canadian Electrical Code - Part 1, Section 28. 208V defrost circuits employ No. 12 AWG field wire leads for field connections. On remote cases intended for end to end line-ups, bonding for ground may rely upon the pull-up bolts.




L5P Domestic & Export (50Hz) Case Circuits (8' Cases)






## **Canopy Lighting Circuits**



## **Optional Shelf Lighting Circuit**



## **GENERAL INFORMATION**

### **Mirror Installation**

When installing mirrors you must be aware that on longer line-ups it is possible to end up with a gap at the end of the line-up. To help prevent this, leave a gap at the starting end that can be covered by the stainless steel trim. Additional mirror positioning adjustments may be required to make sure the gaps at each end of the line-up don't show when the stainless steel trim is in place. Also make sure all mirrors have a good tight seal between each mirror.

### Water Spray Accessories


### WARNING

When using water spray accessories it may be necessary to install approved antibackflow devices in the water supply line. Local codes should be checked in this regards. Installation of this device is the responsibility of the end user and would be performed by plumbers.

#### **CAUTION**


Do not spray lighted shelves when using any water spray accessories. Moisture on light fixtures could cause an electrical short and/or damage the case operating system.

The water supply pressure should not exceed 45 lb to assure proper operation. Water supply pressures above 45 lb should use a pressure reducing valve.



The spring coil spray hose or retractable spray hose are the two manual systems available for produce cases. To use the retractable spray hose, pull the nozzle and hose out smoothly to the desired length. When the reel rachet sounds, let the hose back against the rachet to hold it in place. To rewind, pull hose out slightly to release the reel rachet, then guide the hose back into the front of the case. Do not allow hose to rewind by itself. Hose jamming and/or reel damge could result.

#### **Retractable Hose Replacement**



- 1. Pull hose (1) completely out of front of case (2) and engage reel rachet.
- 2. Fasten locking pliers on the reel edge (3) to prevent the reel from accidentally rewinding. The reel spring is fully wound in this position.
- Remove hose (1) from hose clamps on the reel (3) and disconnect hose end fitting (4) from swivel assembly (5). Remove hose (1) from reel (3) and front of case (2).

### **CAUTION**

Do not allow the reel to unwind suddenly or attempt to turn reel clockwise. This will damage the spring motor in the reel.

#### NOTE

If reel spring is unwound, wind the reel 19 complete turns counterclockwise, engage the reel rachet and install locking pliers on reel edge.

- 4. Insert hose (1) through the front of the case (2) and the hole in the reel (3).
- 5. Apply pipe dope to threads of hose end fitting (4). Install hose end fitting (4) in the swivel assembly (5).
- 6. Attach the hose (1) securely to the reel (3) with the hose clamps on the reel.
- 7. Retract the hose (1) onto the reel (3).


#### NOTE

If reel does not work properly after rewinding, replace the reel assembly.

### **Produce Handling Tips**

Fresh fruits and vegetable are living things, even after they have been harvested. They continue the process of respiration and transpiration after harvesting. Respiration is the process of self feeding to provide energy for maintaining life. (EXAMPLE: Asparagus and sweet corn generate heat after they are picked.) Transpiration is the process of water loss through vapor from the plant tissues. Post-harvest life can be maintained by slowing the rate of water loss. Refrigeration lowers the rate of respiration and transpiration. Store most types of produce close to freezing prior to display. There are a number of explanations (ex. Cucumbers can be kept relatively cool by themselves, but could be damaged by temperatures below 40°F). See chart on following pages for specifics.

Non-refrigerated produce cases are called "Dry" cases. They are used to display potatoes, dry onions, bananas, avocados and other products which don't need refrigeration. These cases can also be used with a bed of cracked ice to display perishables. Refrigerated produce cases displays produce products that require refrigeration. The refrigeration coil is below the display and fans are used to circulate air through the case display. This moving air will pick up moisture from unwrapped produce and carry it to the coil. It is necessary to replace this moisture by using a water spray several times during the day. At night the produce should be covered wih a wet cloth. The alternate to sprinkling is to wrap the produce.



In order to maintain case air flow, the return air duct must not be blocked by product. An important aid to improve air circulation is to use air deflectors below the elevated screens in the case. These deflectors will direct the air flow into the display and prevent cool air from "short circuiting" the display. Deflectors are furnished with hump screen option. See illustration.

### Produce Handling Chart

Ideal Storage Conditions				Γ	Display Rack Care	
Produce	Temperature (°F)	Relative <u>Humidity (%)</u>	Sell Quickly <u>(1-2 days)</u>	Refrigerate (40°F)	Sprinkle with Water	Special Notes
Apples	30-32	85-95	·	Helpful	No advantage	Avoid bruising
Apricots	31-32	85-90	Yes	Helpful	No	0
Asparagus	32-36	90-95	Yes	Profitable	No	Trim butts and stand in ice or shallow water
Avocados	40-55	85-90	Yes	No	No	Display on padded surface
Bananas, Ripe	56-58	85-90	Yes	No	No	Display on padded surface
For Ripening	58-68	90-95		No	No	Avoid bruising
Beans, Lima	32-40	85-90	Yes	Profitable	No	Shake up to aerate
Beans, Snap	40-45	90-95	Yes	Profitable	Yes	
Beets	32	85-95	Yes	Profitable	Yes	Moisten roots only
Berries	31-32	90-95	Yes	Helpful	No	Keep well ventilated
Broccoli	32-35	90-95	Yes	Profitable	Yes	Keep out of sun
Brussel Sprouts	s 32-35	90-95	Yes	Profitable	Yes	Remove yellow leaves
Cabbage	32	90-95		Helpful	Yes	
Carrots	32	90-95		Profitable	Yes	Moisten roots only of bunches
Cauliflower	32	90-95	Yes	Profitable	Yes	Sprinkle only if refrigerated
Celery	31-32	90-95	Yes	Profitable Yes		
Cherries	31-32	90-95	Yes	Helpful	No	Keep well ventilated
Corn, Sweet	31-32	90-95	Yes	Profitable	Yes	Keep cold to keep sweetness
Cucumbers	45-50	85-90	Yes	No	No advantage	
Eggplants	45-50	85-90	Yes	No	No advantage	Do not bruise, keep on ice
Grapefruit	50-60	85-90		Helpful	No advantage	Remove decayed fruit
Grapes	30-32	85-95	Yes	Helpful	No	Keep well ventilated
Honeydews	45-50	85-90		Helpful	No	Cover cut melons with transparent film
Lemons	38-40	85-90		Helpful	Yes	Sprinkling may be helpful
Lettuce	32	90-95	Yes	Profitable	Yes	Avoid soaking with water
Limes	48-50	85-90		Helpful	No advantage	
Mushrooms	32-35	80-90	Yes	Helpful	No	Handle carefully, keep dry
Muskmelons	32-35	85-90	Yes	Helpful	No	Cover cut melons with transparent film
Onions, Dry	32	65-70		No	No	Remove loose wrappers, keep dry
Onions, Green	32	90-95	Yes	Profitable	Yes	Keep well ventilated
Oranges	34-38	85-90		Helpful	No advantage	Remove decayed fruit
Parsnips	32	90-95		Helpful	Yes	Moisten roots only
Peaches, Ripe	31-32	90	Yes	Helpful	No	Ripen at room temperature before storage
Pears	29-31	90-95	Yes	Helpful	No	Display in single or double layer on pads

	Ideal	Storage Condi	tions	D	isplay Rack Care	
٦ <u>Produce</u>	emperature <u>(°F)</u>	Relative <u>Humidity (%)</u>	Sell Quickly <u>(1-2 days)</u>	Refrigerate (40°F)	Sprinkle with Water	Special Notes
Peas, Green	32	90-95	Yes	Profitable	Yes	Shake up to aerate, keep cold
Peppers	45-50	90-95	Yes	Profitable	Yes	
Pineapples, Ripe	45-55	85-90	Yes	No	No	Remove decayed fruit
Plums	31-32	90-95	Yes	Helpful	No	Remove decayed fruit
Potatoes	40-50	85-90		No	No	Keep out of sun
Radishes	32	90-95	Yes	Profitable	Yes	Keep water off tops, avoid tight packing
Rhubarb	32	90-95	Yes	Profitable	No	Trim thin slice off stems and stand in cold water
Squash, Summe	r 40-50	85-95	Yes	Helpful	Yes	
Winter & Pmpk	ns 50-55	50-75		No	No	
Spinach	32	90-95	Yes	Profitable	Yes	Keep ventilated
Sweet Potatoes	55-60	85-90		No	No	Keep ventilated
Tangerines	32	85-90	Yes	Profitable	Yes	Remove decayed fruit
Tomatoes, Ripe	45-50	85-90	Yes	Helpful	No	Sell quickly, refrigerate to hold
Tomatoes, Greer	า 55-70	85-90		No	No	Ripen in back room, sort frequently
Turnips	32	90-95		Profitable	Yes	Sprinkle roots only
Watermelons	40-45	80-85		Helpful	No	Cover cut melons with

The "Produce Handling Chart" is courtesy of Produce Marketing Association, Inc., Newark, Delaware 19711, from their 1973 Yearbook. This book is published as a service to the Fresh Produce Industry.

#### For additional information, consult:

"The Commercial Storage of Fruits, Vegetables, and Florist and Nursery Stocks", USDA Handbook No. 66, 1968.

transparent film

"The Shelf Life of Fresh Fruits and Vegetables - Retail Store Display Cases", USDA HT&S Office Report No. 247, October 1951.

"Fresh Fruits and Vegetables - Handling and Care", Corporate Extension Service, Michigan State University.

## L5P SERVICE INSTRUCTIONS

See "General I&S Manual" for T-8 lamp, and ballast, fan blade and motor, and color band and bumper replacement instructions.

### **Ballast and Lighting Locations**

All light ballasts are located under the canopy and mounted on the top of the canopy light channel. This includes remote ballasts for optional shelf lights. The canopy light(s) are under the canopy light channel in the top of the case. The optional shelf lights are mounted under the top interior liner above each shelf section.

## PARTS INFORMATION


### **Cladding and Trim Parts List**

Item Description

L5P


		8′	12′
1	Screw	5183536(4)	5183536(6)
2	Screw	5183536(5)	5183536(7)
3	Hood Close-off	9026069	9026070
4	Screw (per end cover)	5183536(4)	5183536(4)
5	End Cover	9026103(2)	9026103(2)
6	Canopy Hood, Painted	9025223	9025224
7	Canopy Hood Backer, Painted	9025983	9025983
8	Screw	5199134(4)	5199134(4)
9	Bumper Retainer / Handrail	color pe	r order
10	Color Band, Painted	9023798	9023800
11	Handrail Backer, Pntd.	9025316	9025316
12	Bumper Backer	color per	order
13	Color Band Backer, Painted	9040223	9040223
14	Bumper End Trim	color per	order
15	Bumper	color per	order
16	Upr. Frt. Cladding, Painted	9025201	9025202
17	Rivet	5104702(4)	5104702(6)
18	Screw, Shoulder	9025833(6)	9025833(8)
19	Lwr. Frt. Cladding, Painted	9025203	9025204
20	Screw	5183536(6)	5183538(8)

## Tyler Refrigeration



## Installation & Service Manual

Item Description		8′	12′		
21	Kickplate	color pe	color per order		
22	Kickplate Backer	9041790	9041790		
23	Screw	5183536(6)	5183536(8)		
24	Kickplate Support	9041329(3)	9041329(4)		
25	Screw	5183536(6)	5183536(8)		
26	Raceway	9025127	9025128		
27	LH End Close-off, Painted	9022459	9022459		
	RH End Close-off, Painted	9022466	9022466		
28	Horizontal Joint Trim	9025959	9025959		



## **Operational Parts List**

Case Usage	Domestic		Export	
Electrical Circuit	115 Volt 60 Hertz		220 Volt 50 Hertz	
Case Size	8′	12′	8′	12′
Fan Motor	5125532 5 Watt	5125532 5 Watt	5057657 7.5 Watt	5057657 7.5 Watt
Fan Motor Brackets	5205112	5205112	5205112	5205112
Fan Blades (8.75" 20° 5B)	5231809	5231809	5231809	5231809
T-8 Lamp Ballast (canopy or shelf) (3 lamp)	5991030	5991030	9028438	9028438
T-8 Lampholder (canopy)	5232279	5232279	5232279	5232279
T-8 Lampholder (shelf)	5092414	5092414	5092414	5092414
Light Switch (SPST)	5100565	5100565	5100565	5100565

For information on operational parts not listed above contact the TYLER Service Parts Department.